



### **Installation Instructions for Medallions, Appliqués, Cartouches & Corbels\***

1. Before installing the product, ensure you have the product on-hand to assist you with taking exact measurements.
2. If you are installing a medallion, we recommend leaving it in the box until you are ready for installation. **Remove medallion from box by grasping inner center rim.**
3. Locate and mark the wall studs/ceiling joists where the product will be mounted. Pre-drill the product before fastening. Coated drywall screws work best for mounting, or you may use coated nails with head or other coated fasteners.
4. Apply adhesive (such as Liquid Nails or drywall board adhesive) to the back of the product to ensure bonding to the wall or ceiling. **Adhesive must be used for medallion installation.**
5. Use coated screws to fasten product to the studs or joists and check to assure that product is secured to wall or ceiling. Use coated toggle bolts if studs or joists are unavailable. Countersink the coated screws 1/8" or less and fill the holes with non-shrinking spackling compound using a feathering technique to blend it in with the product.
6. If the wall or ceiling is uneven with the product, apply painter's caulk with caulking gun to fill in the gap along the outer edge of the product.
7. **For medallions:** If you are using your medallion around a light fixture, center the hole over the electrical box. Use coated extension screws for mounting the top plate of the light fixture through the hole of the medallion to the electrical box. **NOTE: Extra blocking may be needed as lights/fixtures must be attached independently of medallion. Do not use the medallion to support the fixture.**
8. Cast Designs products accept finishing well. Prime and paint; or, seal, stain, and varnish; or faux finish. For ease of installation, we recommend applying finish to the product first and then touching up as needed.

*\*User shall determine and assume full responsibility for the suitability and installation of the product*